



*Nothing else measures up!*

**Follow us!**



Prospect House  
George Cayley Drive  
Clifton Moor  
York  
England  
YO30 4XE

Tel: +44 (0) 1904 692723  
Fax: +44 (0) 1904 690385

E-Mail: [sales@yorksurvey.co.uk](mailto:sales@yorksurvey.co.uk)



## Stopwatch



**Code: 34250**

## Operating Instructions

# Stopwatch Operation

## Features:

Multi-purpose stopwatch  
Start, stop, re-start and split time  
Large, easy to read display  
Alarm chrono

## To set alarm

Press A twice (hours will flash)  
Press B to advance hours  
Press C (minutes will flash)  
Press B to advance minutes  
Press A to save

## To set time and date

Press A three times (seconds will flash)  
Press B to zero seconds  
Press C (minutes will flash)  
Press B to advance the minute to correct time  
Press C (hours will flash)  
Press B to advance hours

Press C display will change to date (day of month will flash)  
Press B to advance day of month  
Press C (month will flash)  
Press B to advance month  
Press C (day of week will flash)  
Press B to advance day of week

Press A to save

## To use Stopwatch

Press A once to display stopwatch

Press B once to start timer

Press C once for split time  
Press C again to resume

Press B once to stop  
Press B once to restart

Or

Press C to zero

Press A to return to clock

